



FOKKER D VII
 THE NEW CONSTRUCT-A-PLANE CO.
 BROOKLYN N. Y.
 WING SPAN 15 INCHES
 LENGTH-OVER-ALL 11 1/2 "
 DRAWN BY - H. APPEL

SIDE VIEW

Fok. D VII 7746

FOKKER D VII

- 1-STUDY PLANS CAREFULLY
- 2-LAY OUT SIDES OF FUSELAGE ON SHADED LONGERONS, SHOWN ON SIDE VIEW. CEMENT UPRIGHT BRACES IN PROPER PLACES.
- 3-CUT OUT FUSELAGE FORMERS.
- 4-WHEN SIDES HAVE DRIED, CEMENT FORMERS IN PLACE.
- 5-CUT OUT PARTS OF TAIL SURFACES. CONSTRUCT RUDDER AND ELEVATOR AS SHOWN.
- 6-CUT OUT WING RIBS. ASSEMBLE WING AS SHOWN
- 7-CUT OUT PARTS OF LANDING GEAR AND ASSEMBLE AS INDICATED
- 8-COVER ENTIRE MODEL. START WITH TAIL SURFACES, THEN COVER WINGS AND FUSELAGE
- 9-ASSEMBLE MODEL, BEING CAREFUL THAT PARTS ARE CEMENTED IN THEIR PROPER POSITION.

CEMENT TO FUSELAGE

CEMENT TO RUDDER

ELEVATOR

CEMENT TO TOP WING

CUT OUT AND CEMENT TO LOWER WING

ELEVATOR PARTS SHADED

RUDDER

FRONT VIEW

CUT OUT AND CEMENT TO TOP WING.

CEMENT TO LOWER WING

9/16" DIHEDRAL

11/16" DIHEDRAL

1/16" SQ.

1/16" SQ.

1/16" SQ.

1/16" x 1/8"

1/16" x 1/8"

1/16" x 1/8"

1/16" SQ.

PROP SHAFT

N STRUTS FULL SIZE

LONGERONS

SPLICE

R5

R4

R3

R2

R1

R2

R3

R4

R5

W3

W3

W2

W4

R9

R8

R7

R6

R7

R8

R9

1

3

4

F5

F6

F7

F8

F1

F2

F3

F4

F9

R1

R3

R2

E1

2

3

C1

C2

F5

F6

F7

F8

2

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

