



NOTE: ALL RIBS AND BULKHEADS ARE 1/16" HARD SHEET Balsa UNLESS OTHERWISE SPECIFIED.

RIB DETAILS

BULKHEAD DETAILS

TOP VIEW

ENGINE INSTALLATION AND MAIN GEAR DETAILS

FRONT VIEW

SIDE VIEW

NOSE GEAR STRUT INSTALLATION DETAILS

WIRE STRUT LAYOUTS

AIR INLET TUBE DETAILS

"SCORPION" INSTALLATION DETAILS

NOTE: USE SAME ENGINE MOUNT ARRANGEMENT AS IN "150", BUT ADD 3/8" THICK SHEET Balsa SPACER.

NOTE: USE SAME HATCH OPENING AS "150" BUT MOVE MOUNTING FORWARD, BETWEEN F-5 AND F-6.

SCALE IN INCHES

