



-F1 is 2 lams. of 1/16 hard -
all other formers are 1/32 med.
-all stringers are 1/16x1/32 med.
-cut missing stringer slots after
assembly to prevent wavy stringers
-add bottom stringers after installing wing

COLOR SCHEME
standard British WWII
camouflage

SEE MAY 1971 AAM
FOR 3-VIEWS

MARTIN-BAKER MB5
PEANUT SCALE
Designed & Drawn by:
MARK DRELA