

SAAB A37 VIGGEN.

Ray Malmström, 1967.

N.B. You can make the block for the nose cone by cementing three layers of 14 sht together.

