



COCKPIT POD - MAKE FROM FOAM or Balsa BLOCK  
HOLLOW AS SHOWN

BLOCK TIP (HOLLOW AS SHOWN)

BLOCK LE. (HOLLOW AS SHOWN)

R6

R5

R4

1/8x1/4-in. Balsa - TOP + BOTTOM

R3

"DROP TANK" STRUT

1/8-in. Balsa FULL-DEPTH SHEAR WEBS

R2

HATCH (BOTTOM SURFACE)

R1

TRAILING EDGE - 1/4-IN. Balsa  
- ADD AFTER TRIMMING SKINS

GRAIN

APPROX. SHEETING PLAN SHOWN THUS

INSET STAB AS SHOWN  
TAILOR INSET TO MATCH  
STAB MAX. THICKNESS

ELEVATOR SERVO (2 REQD)

SLOT FOR SUPPORT RIB

MOTOR WIRING

TAPE HINGE

STAB ELEVATOR - 3/8-IN. Balsa

- Balsa TUBE "NACELLE"
- 1/8-IN. PLY SUPPORT RIB
- 3-48 BOLTS - 4 PLACES (CSK HEAD)
- SHEET ALUM MOTOR MOUNT
- AXI 2212/34 MOTOR
- AXI REVERSE-MOUNT PROP "STUD"
- 1/8-IN. PLY BACKPLATE
- Balsa SPINNER - GLUE TO BACKPLATE

SCALE RUDDER HINGE LINE  
RUDDER/FIN - 3/8-IN. Balsa  
- BUTT GLUE TO BODY

