



PROPELLOR USE
ANY 5/8" PLASTIC
K HOBBY PROP

Balsa
has BETTER

TAIL PLANE PATTERN

'NORTH PACIFIC'
PLASTIC
WING MOUNT

FRONT OF TAIL PLANE (1/20" OR 1/32" Balsa)

WING - 1/16" Balsa

CUT TO GIVE SWEEP BACK TO WINGS

1/16" SHEET Balsa.

HAIF SCORE FROM UNDERNEATH
AND GENTLY BEND UP (CEMENT NEEL)

DIHEDRAL ANGLE.

1/2"

1/4"
7/16"
BOLOR
DEGRADANCE
1247

NOTE
GRAIN DIRECTION

PM

3/16" x 1/4"

PM

1/32" SHEET
Balsa (2 OFF)

GLUE

RUBBER
BAND

GLUE

20G BAND WIRE

CEMENT

1/16" Balsa
UNDERFIN.

1/20" SHEET Balsa.
(SANDPAPER
1/16" THIN OR
USE 1/32" Balsa)

1/4" x 3/16" MEDIUM Balsa

CAUTION: DON'T OVER-WIND RUBBER - ONE ROW OF KNOTS
IS ENOUGH!

BUILD IN 2 HOURS.

Super Streak

Aus TRAKIPIV Modeler 1974

KIDS! WRECKED YOUR 'SLEEK STREAK' KIT MODEL? KEEP THE PROPELLOR UNDERARRANGE WING MOUNT
BUY SOME Balsa AND BUILD THIS SUPER HIGH-FLYING HIGH PERFORMANCE MODEL. USE A LONGER
LOOP OF RUBBER FOR LONGER FLIGHTS. (OR BUILD FROM SCRAPTY, WITH OTHER COMMERCIAL PARTS FROM HOBBY SHOP)