



NOTE - THIS SIDE OF FUSELAGE SHOWS MOTOR STICK WITHOUT #14 AND #15 ON.

32 SQ. BAMBOO REINFORCEMENT
 1/16" SQ. BAMBOO REINFORCEMENT
 3/32" SQ. BAMBOO REINFORCEMENT
 1/16" SQ. BAMBOO REINFORCEMENT
 1/32" SQ. BAMBOO REINFORCEMENT

MAKE 4 N°1.
 MAKE 2 N°2, 3 & 4.
 MAKE 4 N°6.
 MAKE 2 N°5 & 7.
 MAKE 1 N°8 & 9.

MOTOR NOSE DISK
 MAKE 2 N°10 & 11

MAKE 6 N°17.
 MAKE 2 N°18.

- 1 TO 4 - RIBS
- 5 TO 9 - FUSELAGE FORMERS
- 10, 11 - MOTOR NOSE DISK
- 12, 13 - COCKPITS
- 14, 15 - MOTOR COVERINGS
- 16 - REAR HOOK
- 17 - PROP BLADES
- 18 - PROP HUB

BOEING BOMBER			
SPAN	12"	HEIGHT	2 3/8"
LENGTH O.L.	8 1/2"	WEIGHT	1/4 Oz.
CONSTRUCT-A-PLANE CO.			

CUT OUT #12, 13, 14, 15 AND CEMENT IN PROPER PLAC.