

Shooting Star

By
COMET

Try **COMET**
NU-DOPE

ASSEMBLE WING DIRECTLY OVER PLAN. TO KEEP PARTS FROM STICKING TO PLAN, PLACE WAX PAPER OVER IT.

SHAPE BLOCK AFTER IT IS CEMENTED IN PLACE

ROUND OFF STRIP MAKE 2

ACTUAL LENGTH LANDING GEAR STRUTS

BUBBLE CANOPY MAY BE MADE FROM CELLULOID OR CUT FROM PLAN

1ST STEP IN CONSTRUCTING WING.

2ND STEP PUTTING IN DIHEDRAL. NEXT COVER WING WITH PAPER, EXCEPT BETWEEN RIBS 'A' ON UPPER SURFACE.

LOWER FILLETS

1/4" THICK BLOCKS


MAKE NOSE-WHEEL STRUT FROM PAPER CLIP

WHEEL COVER

WING FILLETS

1ST STEP IN BUILDING FUSELAGE. NEXT ADD STRIPS. (SEE ABOVE)

AIR SCOOP CEMENT IN PLACE AFTER MODEL IS COVERED AND ASSEMBLED



A3 SHOOTING STAR